

# ATV-AC-F65 and ATV-AC-F650 Prowler Front Kick Panels

## Tools Needed For Installation

Drill with 1/4" Drill Bit  
7/16 Open End Wrench  
5/32 Allen Wrench  
Wire Crimpers / Strippers

## Installation Instructions:



Align the kick panel in the upper corner of the footwell and mark the 3 mounting holes



After marking the holes, drill them using a 1/4" drill bit



Once the holes are drilled, mount the kickpanel using the supplied hardware



Drill a hole through the pod for your speaker wire



After securing all the allen bolts and the 7/16 nuts run your speaker wire into the speaker pod



After attaching the speaker wires to the speaker, install the speaker into the Wet Sounds pod.



Wet Sounds Inc. 9330 West Airport Blvd Suite 170 Houston, TX 77031  
www.wetsounds.com 1-877-938-7757