

# ATV-KT-F65 and ATV-KT-F650- Teryx Front Upper Panel

## Tools Needed For Installation

Drill with 1/4" Drill Bit  
7/16 Open End Wrench  
5/32 Allen Wrench  
Wire Crimpers / Strippers

## Installation Instructions:



Align the speaker panel in the upper side corner of the footwell and mark the 2 holes



After marking the holes, drill them using a 1/4" drill bit



Drill a hole through the top of the pod for your speaker wire



Once the holes are drilled, mount the kick panel using the supplied hardware



After securing all the allen bolts and the 7/16 nuts run your speaker wire into the speaker pod and attach wire to speaker



After attaching the speaker wires to the speaker install the speaker into the Wet Sounds kick panel.



Wet Sounds Inc. 9330 West Airport Blvd Suite 170 Houston, TX 77031  
[www.wetsounds.com](http://www.wetsounds.com) 1-877-938-7757