

# ATV-RAN-SUB10 - GEN 2 Center Console Sub Box

## Tools Needed For Installation

Drill with 1/4" Drill Bit  
Phillips Screwdriver / Cordless drill  
Wire Crimpers / Strippers



## Installation Instructions:



If the Subwoofer is not already mounted in the box, do so now using the screws provided (we recommend you pre drill the holes using a 1/8" drill bit to make screwing in the subwoofer easier. Drill a 1/4" hole in the lower front of the box to run the speaker wire out of the enclosure. **NOTE: Sealing this hole to prevent air leaking will improve sound quality**



Place the enclosure on the passenger side footwell and lift the box onto the center hump, lift the driver side higher and slide in using a sideways motion



Continue sliding the box over the hump till it sits in place and makes good contact with the floorboard



Once the enclosure is in place, screw the 6 mounting screws into the floor using a phillips screw bit in a cordless drill

After the enclosure is mounted, pull any remaining speaker wire under the center of the dash. You can now connect the speaker wires to the amplifier

