

ATV-RH-F65 and ATV-RH-F650 - Front Kick Panel

Tools Needed For Installation

Drill with 1/4" Drill Bit
7/16 Open End Wrench
5/32 Allen Wrench
Wire Crimpers / Strippers

Installation Instructions:



Align the kick Panel where you want it mounted and mark the holes



After marking the holes, drill the mounting holes using the 1/4" bit



After drilling the mounting holes drill a hole for the speaker wire where the 2 panels meet using the 1/4" drill bit



Once all the holes are drilled mount the kickpanel using the supplied hardware



After securing the allen bolts with the 7/16 nuts run your speaker wire



After attaching the speaker wires to the speaker install the speaker into the Wet Sounds kick panel