

ATV-RH-SUB10 - Center Console Sub Box

Tools Needed For Installation

Drill with 1/4" Drill Bit
Phillips Screwdriver
Wire Crimpers / Strippers



Installation Instructions:



If the subwoofer is not already mounted in the box do so now, drill a 1/4" hole in the back of the box to run the speaker wire out of the enclosure
Note Sealing the hole to prevent air leaking will improve sound quality

Run the subwoofer wire to the location that you are mounting your amplifier
Drilling a 1/4" hole to run the wire through the plastic may be necessary



Place the box on the passenger floor of the rhino speaker facing out



Place your hand over the upper corner of the sub box and slide into place over the center hump



Using the supplied hardware locate the factory holes and tighten the screws to mount the Subwoofer Console. After securely mounting, hook up the speaker wires to the amplifier

