

ATV-RZR-R65 and ATV-RZR-R650 - RZR Rear Kick Panel

Tools Needed For Installation

Drill with 1/4" Drill Bit
7/16 Open End Wrench
5/32 Allen Wrench
Wire Crimpers / Strippers

Installation Instructions:



Align the Kick Panel in the corner of the bed and screw into the plastic using the 3 provided screws



After mounting the pod, drill up through the hole in the bottom of the bed using the 1/4" drill bit , this is where your speaker wire will run into the pod



Run the speaker wire into the pod using the hole in the bottom



After attaching the speaker wires to the speaker install the speaker into the Wet Sounds kick panel

