

Important
Please Read
Before Installing!



Wet Sounds PRO60 & PRO80 MC
2007 - 2010 MasterCraft Factory Mount

- 1) Remove 6 screws holding the front baffle onto the housing. And separate the baffle assembly from the main housing. Please note-you do not need to remove the grille or speaker as the speaker is attached to the front baffle.
- 2) Remove acoustic dampening material and set separated housing to the side
- 3) Remove the factory caps with the 4 allen bolts from the factory mounting locations where you will be mounting the PRO60/80 MC (you will not need these parts for installation)
- 4) Feed the factory speaker wire through the center hole of the PRO60/80 MC mounting plate.
- 5) Attach the mounting plate to the tower with the 4 allen bolts included with the PRO60/80 MC. **IMPORTANT:** (The plate should be attached with the longer end towards the front of the boat.) It is suggested that you use lock-tite on all bolts.
- 6) Take the empty housing and feed the speaker wire through the center hole. Continue to slide housing up to the adapter plate. The two bolts should line up with the locations on the housing.
- 7) Use the included hardware to bolt the housing to the tower plate. You should have a flat washer, lock washer and nut. Please make sure that these nuts are tight.
- 8) Once your housing is bolted tight to the tower. Connect the factory positive wire to the + IN wire (*Blue Wire*) on the PRO60/80 MC crossover. And connect the factory negative wire to the - IN (*black wire that is directly next to the blue wire*) *Please refer to the factory manual for Mastercraft speaker color codes.*
- 9) Insert the acoustic dampening material.
- 10) Take the front baffle and hold it up to the housing.
- 11) Connect the “soldered” white wire to the + positive (*Red*) push down terminal on the compression horn. Connect the “soldered” black wire to the - negative (*Black*) push down terminal on the compression horn.
- 12) Connect the wire with the spade connector (*Red*) to the + positive of the mid bass woofer. Connect the wire with the spade connector (*Black*) to the - negative of the mid bass woofer.
- 13) Press the front baffle onto the housing.
- 14) Attach the 6 stainless screws around the front baffle to the housing using a hand screw driver. Please make sure these are tight but DO NOT over tighten.
- 15) Finished. Enjoy your Wet Sounds PRO60/80 MC speakers!