

Zone Controller Operation Guide

Shadow-caster LED Lighting

www.shadow-caster.com

REV A 9/8/2012



Co-Developed with Wet Sounds the "Zone Controller" allows individual or simultaneous control of four separate lighting zones on your boat or RV. Quickly change color and brightness or set the lights to dance to music.

Supports Shadow-Caster's "Shadow-Net" devices. This allows communication with Shadow-Caster's line of under water and above water lights, along with standard RGB Color Changing lights.

The backlit housing installs in a 3" gauge opening and includes a wiring harness and mounting hardware.

Zone button backlighting will allow each button to match the selected color and mode of that zone

Turn controller on

- Press ALL

Turn controller off

- Hold OFF for 2 secs

Initiate lighting

- 1) After controller has been turned on by pressing ALL, press ALL again and all lights will return to previous setting.
- 2) Press ALL, or press the desired zone number then press desired color for full brightness
- 3) Press and hold a color and lights will fade up from black and stop when button is released
- 4) Press Color then < or > to shift color hue
- 5) Press SYNC to activate music sync
 - Press <, >, ^, v to affect the music sync intensity and color pallets
- 6) Press MODE to activate color changing / fade modes
 - Press one time for single color fade/strobe
 - Press two times for multicolor fade/strobe
 - Press <, >, ^, v to affect the mode intensity and color pallets

Dimming

- Press ALL, or press the desired zone number then press or hold ^ or v

Turn zones off

- Press ALL, or press the desired zone number then press OFF